



The Garden Gym

NB- Before you start!

Ensure that the first pull up bar is solid. You will connect the monkey bar to the original pull up bar which will create movement in the foundations. We recommend that you let the pull up bar concrete harden before starting to add the monkey bar. Depending on the mix you used this would be between 2-4 hours.



Height adjustable bar
Installation guide

General guidance

These instructions are provided as a guide to help you install your equipment. Depending on the type of ground conditions it may be necessary to modify the installation. If you are unsure, please consult a qualified professional or contact the Garden Gym Team. The installation should be carried out by 2 people. Before digging you must ensure that there is no risk of encountering services such as drains or electricity.

The Garden Gym does not accept any liability in relation to the installation and subsequent use of the gym relating to incorrect or improper installation.



You will need

Spade / hole diggers / safety gloves / step ladder / tape / measure / level / 2 x 19mm socket drivers / hammer



Post mix


Between 1 and 2 bags per post, depending on the size of your holes and ground conditions



The Garden Gym

Height adjustable bar
Installation guide

1



Select location and mark out

Using the adjustable bar as a guide, decide on the orientation of the bar, lay out on the ground to find the position of the post. The bar can be orientated in any direction but take care to avoid clashes with any of the holes in the posts or to create any trapping points by overlapping bars.


2



Digging the holes

Digging the holes for the posts is a key part of the installation. The hole must be a minimum of 600mm deep (700mm for 3.6m posts). You will notice that the post has a 12mm hole on the lower section, this is to take the supplied metal bar which is to be inserted prior to concreting. Ensure that the hole is large enough to take this bar. Leave plenty of space for alignment.

3



Reinforcing rods

We supply metal rods to provide additional support to the foundation. Insert the rod through the hole in the post prior to adding the concrete to each hole

4



Insert the post, concrete and level


Insert the post into the hole. Level the post in all directions and fix with the post mix following the product instructions. This post will need to set prior to moving to the next step.



The Garden Gym

Height adjustable bar
Installation guide

5



x8

Fix the bar in place

Ensuring the post has set in the concrete, the bar can be fixed in place using the 8 supplied coach screws, washers and cover caps. Select the position of the bar and mark out the 8 x hole positions. Drill a 4mm pilot hole before screwing the bar in place. Fit the cover caps over the screw heads.

Foundations



The stability of your Gym relies on correct installation of the posts. We recommend a minimum depth of 600mm. Ensure the concrete is fully hardened before use (2-3 days) and the hole is suitable for the ground conditions and planned usage. We also recommend using a small amount of pea shingle at the base of the post to aid drainage.



Maintenance

All of our materials are maintenance free, the posts are supplied with a tanalised finish and 10 year life expectancy. **It is essential to check the bolts and fixings on a monthly basis and tighten where necessary as they can loosen off as the timber goes through the natural drying process.**

Train Safe!



1. Always consult your doctor before undertaking any physical exercise.
2. Injuries to health may result from excessive, incorrect training or using the equipment in a way that it is not designed for.
3. Remove jewellery, watches or anything else that may catch or snag before exercising.
4. Always warm up prior to exercising, if you are unsure consult a health professional for advice.
5. Children should not be allowed to use the equipment without the strict supervision of adults who are aware of how to exercise correctly.
6. Our products have been designed to carry out exercise and are not meant as a climbing frame or piece of play equipment. The user is wholly responsible for any accidents or injuries occurring from usage of the equipment regardless of proper or improper usage.
7. The Garden Gym Ltd disclaims all liability from the mis-use or incorrect installation of our products.
8. The user must not adapt, amend or remove any part of the equipment.

